

Required Tools: (Not included)

- A. 3 mm Allen wrench
- B. 8 mm wrench
- C. Phillips screwdriver

⚠ WARNING

⚠ CAUTION: To avoid potential shock or other injury, turn power switch OFF and disconnect charger before conducting any assembly or maintenance procedures. Failure to follow these steps in the correct order may cause irreparable damage.

Step 1

Using a 3 mm Allen wrench and a 8 mm wrench, loosen and remove the bolt and lock nut at the back of the headlamp.

**Step 2**

Using a Phillips screwdriver, remove the two (2) screws that hold the headlamp holder onto the front fork.



Step 3

Reverse the steps.

ATTENTION: Charge battery 12 hours before using.