

Required Tools: (Not included)

A. Two (2) 5 mm Allen wrenches

⚠ WARNING

⚠ CAUTION: To avoid potential shock or other injury, turn power switch OFF and disconnect charger before conducting any assembly or maintenance procedures. Failure to follow these steps in the correct order may cause irreparable damage.

Step 1

Using two (2) 5 mm Allen wrenches, loosen the coupling bolt and remove it.

**Step 2**

Make sure to place your thumb or hand on the side to prevent the ball bearing from jumping away as you slide the foot peg out from the frame.



Step 3

When installing the new foot pegs, make sure to insert the spring and then the ball bearing in place.



Step 4

The side of the foot peg with the spring and ball bearing needs to face the side with the three (3) holes on the frame.



Step 5

Reverse the steps.

ATTENTION: Charge battery 12 hours before using.