

**Required Tools: (Not included)**

- A. 3 mm Allen wrench
- B. 5 mm Allen wrench
- C. Flat screwdriver

**⚠ WARNING**

**⚠ CAUTION:** To avoid potential shock or other injury, turn power switch **OFF** and disconnect charger before conducting any assembly or maintenance procedures. Failure to follow these steps in the correct order may cause irreparable damage.

**Step 1**

Using a 3 mm Allen wrench, loosen the set screws under the throttle and move it away from the grip. Be careful not to damage the wires.

**Step 2**

Using a 5 mm Allen wrench, loosen the bolt on the brake lever clamp and move the lever away from the grip.



### Step 3

Using a small flat screwdriver, insert the blade between the grip and the handlebar. Apply a few drops of WD40® or soapy water. Remove the screwdriver and pull firmly on the grip to remove it from the handlebar.



### Step 4

Reverse the steps to install the new grips.

**ATTENTION: Charge battery 6 hours before using.**