

Required Tools: (Not included)

- A. 3 mm Allen wrench
- B. 5 mm Allen wrench
- C. Flat screwdriver

⚠ WARNING

⚠ CAUTION: To avoid potential shock or other injury, turn power switch OFF and disconnect charger before conducting any assembly or maintenance procedures. Failure to follow these steps in the correct order may cause irreparable damage.

Step 1

Using a 3 mm Allen wrench, loosen the set screws under the throttle and move it away from the grip. Be careful not to damage the wires.

**Step 2**

Using a 5 mm Allen wrench, loosen the bolt on the brake lever clamp and move the lever away from the grip.



Step 3

Using a small flat screwdriver, insert the blade between the grip and the handlebar. Apply a few drops of WD40® or soapy water. Remove the screwdriver and pull firmly on the grip to remove it from the handlebar.



Step 4

Reverse the steps to install the new grips.

ATTENTION: Charge battery 6 hours before using.