

Required Tools: (Not included)

A. 14 mm Allen wrench

⚠WARNING

⚠CAUTION: To avoid potential shock or other injury, turn power switch OFF and disconnect charger before performing any assembly or maintenance procedures. Failure to follow these steps in the correct order may cause irreparable damage.

Step 1

Using two 14 mm Allen wrenches loosen both axle lock nuts.

**Step 2**

Make sure the secure washer is away from the fork. Then remove the wheel.

**Step 3**

Slide down the front wheel to remove it.

**Step 4****Reverse the procedures**

- Re-attach front wheel.
- Secure lock nuts with 14 mm Allen wrenches.

Attention: Charge battery 12 hours before using.