



OWNER'S MANUAL

Read and understand this entire manual <u>before</u> allowing child to use this product! For assistance contact Razor.

DO NOT RETURN TO STORE.

NOTE: Manual illustrations are for demonstration purposes only. Illustrations may not reflect exact appearance of actual product. Specifications subject to change without notice.

Please have your product along with th	e 22 character	product I.D. code with you
before contacting Razor for warranty	assistance and	d/or replacement parts.
Product I.D. Code:		-

CONTENTS

Safety Warnings	1-2
Before You Begin	
Assembly and Set-Up	
Pre-Ride Checklist	

Repair and Maintenance	6
Product Parts	
Warranty and Contact Information	10

SAFETY WARNINGS

A AN IMPORTANT MESSAGE TO PARENTS:

Razor products, like the RipRider 360 Mini, are intended to allow younger children to learn and to enjoy their early experiences using ride-on toys. Studies suggest that children at age 3 have the coordination required to use a steering wheel or handlebar and can use a tricycle. Adult supervision is required as children learn and grow because children do not understand the risks of riding in areas with cars and are at a very high risk of falling off and injuring themselves.

This manual contains important information. For your child's safety, it is your responsibility to review this information and make sure that you instruct your child to follow all warnings, cautions, instructions and safety topics. Razor USA recommends that you periodically review and reinforce the information in this manual with younger riders, and that you inspect and maintain your child's product to ensure their safety.

WARNING: PARENTAL AND ADULT RESPONSIBILITY AND SUPERVISION IS NECESSARY: Riding a RipRider® 360° Mini Caster Trike does present potential risks and caution is required. Because products, like the RipRider 360 Mini, can and do present potential hazards plainly associated with their use, it is well recognized THE NEED FOR EXERCISE OF PARENTAL RESPONSIBILITY IN SELECTING RIDING PRODUCTS APPROPRIATE TO THE AGE OF A CHILD, OR PARENTAL SUPERVISION IN SITUATIONS IN WHICH CHILDREN OF VARIOUS AGES MAY HAVE ACCESS TO THE SAME RIDING PRODUCTS, IS IMPORTANT. Not every product is appropriate for every age or size of child, and different age recommendations are found within this category of product which are intended to reflect the nature of the hazards and the expected mental or physical ability, or both, of a child to cope with the hazards.

Children with any mental or physical conditions that may make them susceptible to injury, impair their physical dexterity or mental capabilities to recognize, understand, and follow safety instructions and to be able to understand the hazards inherent in RipRider 360 Mini use, should not use or be permitted to use products inappropriate for their abilities.

GENERAL WARNING: Riding the RipRider 360 Mini can be a hazardous activity. Certain conditions may cause the equipment to fail without fault of the manufacturer. The RipRider 360° Mini Caster Trike can and is intended to move, and it is therefore possible to lose control, fall off and/or get into dangerous situations that no amount of care, instruction or expertise can eliminate. If such things occur you can be seriously injured or die, even when using safety equipment and other precautions. LIKE ANY OTHER MOVING PRODUCT, USING A RIPRIDER 360 MINI CAN BE A DANGEROUS ACTIVITY AND MAY RESULT IN INJURY OR DEATH EVEN WHEN USED WITH PROPER SAFETY PRECAUTIONS. RIDE AT YOUR OWN RISK AND USE COMMON SENSE.

This manual contains many warnings and cautions concerning the consequences of failing to maintain, inspect or properly use your RipRider 360° Mini Caster Trike. Because any incident can result in serious injury or even death, we do not repeat the warning of potential serious injury or death each time such a possibility is mentioned.

APPROPRIATE RIDER USE AND PARENTAL SUPERVISION

This manual contains important safety information. It is your responsibility to review this information and make sure that all riders understand all warnings, cautions, instructions, and safety topics, and assure that young riders are able to safely and responsibly use this product. Razor recommends that you periodically review and reinforce the information in this manual with younger riders. ALWAYS INSPECT THIS PRODUCT PRIOR TO RIDING. Properly inspecting and maintaining your child's RipRider 360° Mini Caster Trike can reduce injury and ensure their safety. Replace worn parts when they occur.

Do not allow children under age three (3) to use the RipRider 360 Mini. Direct parental supervision is required at all times. The recommended rider age of 3 and older for RipRider 360° Mini Caster Trike is only an estimate, and can be affected by the rider's size, weight or skills. Any rider unable to fit comfortably on the RipRider 360° Mini Caster Trike should not attempt to ride it. Always pay attention to where your child is going; do not allow use of the foot pedals to distract rider from safe riding practices.

A parent's decision to allow his or her child to ride this product should be based on the child's maturity, skill and ability to follow rules.

Keep this product away from very small children and remember that this product is intended for use only by children who are, at a minimum, completely comfortable and competent while operating the RipRider 360° Mini Caster Trike.

DO NOT EXCEED THE WEIGHT LIMIT OF 79 LB (36 KG) ON THE RIPRIDER 360 MINI. RIDER WEIGHT DOES NOT NECESSARILY MEAN A CHILD'S SIZE IS APPROPRIATE TO FIT OR MAINTAIN CONTROL OF THE RIPRIDER 360° MINI CASTER TRIKE.

ACCEPTABLE RIDING PRACTICES AND CONDITIONS

Always check and obey any local laws or regulations which may affect the locations where the RipRider 360° Mini Caster Trike may be used on public property. The RipRider 360° Mini Caster Trike is meant to be used only in controlled environments free of potential traffic hazards and not on public streets. Do not allow your child to ride the RipRider 360° Mini Caster Trike in any areas where pedestrian or vehicle traffic is present.

Ride defensively. Watch out for potential obstacles that could catch the wheel or cause the rider to swerve suddenly or lose control. Be careful to avoid pedestrians, skaters, skateboards, scooters, electric products, bikes, children or animals who may enter your path, and respect the rights and property of others.

Child must maintain a hold on the handlebars at all times. Never carry passengers or allow more than one child at a time to ride the RipRider 360° Mini Caster Trike.

Do not allow hands, feet, hair, body parts, clothing, or similar articles to come in contact with moving parts or wheels while riding.

Never use near streets, swimming pools, hills, steps, sloped driveways, roadways or alleys. Never use headphones, a cell phone or text when riding. Never hitch a ride with a vehicle.

Need Help? Visit our website for replacement parts, product support, a list of authorized service centers in the US and customer service contact information at **www.razor.com**. Please have the product I.D. code (located on the white label of your product) available for better assistance. Additional Customer Service contact information is listed at the back of this manual.

SAFETY WARNINGS

The RipRider 360° Mini Caster Trike is intended for use on solid, flat, clean and dry surfaces, such as pavement or level ground, without loose debris, such as dirt, leaves, rocks or gravel. Avoid sharp bumps, drainage grates, and sudden surface changes as the RipRider 360 Mini may suddenly stop. Wet, slick, bumpy or uneven and rough surfaces may impair traction and contribute to possible accidents. Wet weather impairs traction, stopping, and visibility. Do not ride the RipRider 360° Mini Caster Trike in sand, mud, ice, puddles or water. Avoid excessive speeds that can be associated with downhill rides. Never risk damaging surfaces, such as carpet or flooring, by use of a RipRider 360° Mini Caster Trike indoors. Do not ride at night or when visibility is impaired.

PROPER RIDING ATTIRE

Always ensure child is wearing proper protective equipment, such as an approved safety helmet and keep chinstrap securely buckled. A helmet may be legally required by local law or regulation in your area. Elbow and kneepads, long sleeved shirt, and long pants are recommended. A child should always wear closed toe shoes (lace-up shoes with rubber soles), and keep shoelaces tied and out of the way of the wheels. A child should never ride barefooted or in sandals.

CHECK AND MAINTAIN PRODUCT CONDITIONS

The RipRider 360 Mini should be maintained and repaired in accordance with the manufacturer's specifications, using only the manufacturer's authorized replacement parts, and should not be modified from the manufacturer's original design and configuration.

AWARNING: ALWAYS INSPECT RIPRIDER 360 MINI PRIOR TO RIDING. Properly inspecting and maintaining your RipRider 360 Mini can reduce the risk of injury. Always inspect your RipRider 360 Mini before riding and regularly maintain it. Replace worn parts when they occur.


FAILURE TO USE COMMON SENSE AND HEED THE ABOVE WARNINGS INCREASES RISK OF SERIOUS INJURY. USE AT YOUR OWN RISK. USE WITH APPROPRIATE CAUTION AND SERIOUS ATTENTION TO SAFE OPERATION.

BEFORE YOU BEGIN

Adult assembly required. Remove contents from box. Remove the separators that protect the components from damage during shipping. Inspect the contents of the box for scratches in the paint or dents that may have occurred during shipping. Because the RipRider 360° Mini Caster Trike was partially assembled and packed at the factory there should not be any problems, even if the box has a few scars or dents.

■ Estimated Assembly and Set-Up Time

Allow up to 15–20 minutes for assembly.



WARNING:: DO NOT USE NON-RAZOR PRODUCTS WITH YOUR RIPRIDER 360° MINI CASTER TRIKE. The RipRider 360° Mini Caster Trike has been built to certain Razor design specifications. The original equipment supplied at the time of sale was selected on the basis of its compatibility with the frame, fork and all other parts. Certain aftermarket products may not be compatible and will void your warranty.


Product ID Locations:

(See locations to the left)

- 1. Frame (underneath unit)
- 2. Box side of UPC (not shown)

□ Required Tools

(included)



Plastic Bag Contents:

- Tools
- Owner's Manual


Need Help? Visit our website for replacement parts, product support, a list of authorized service centers in the US and customer service contact information at **www.razor.com**. Please have the product I.D. code (located on the white label of your product) available for better assistance. Additional Customer Service contact information is listed at the back of this manual.

(included)

ASSEMBLY AND SETUP


☐ Attaching the Frame

Required Tools: Two (2) 5 mm Allen Wrenches (included)




1 Using two (2) 5 mm Allen wrenches, remove the coupling bolt on the end of the frame and the coupling bolt in the middle of the frame. Remove and discard the plastic insert.


Note: The coupling bolt in the middle of the frame is shorter.



3 Securely tighten the **(longer)** coupling bolt on the rear frame using two (2) 5 mm Allen wrenches.



2 Insert the rear frame into the frame assembly.




4 Securely tighten the **(shorter)** coupling bolt in the middle of the frame using two (2) 5 mm Allen wrenches.

☐ Attaching the Front Fork

Required Tools: 13 mm Wrench and 5 mm Allen Wrench (included)



1 Remove the steering bolt and locknut from the frame assembly with a 13 mm wrench and a 5 mm Allen wrench.




2 Insert the front fork into the frame assembly.

Need Help? Visit our website for replacement parts, product support, a list of authorized service centers in the US and customer service contact information at **www.razor.com**. Please have the product I.D. code (located on the white label of your product) available for better assistance. Additional Customer Service contact information is listed at the back of this manual.


ASSEMBLY AND SETUP

☐ Attaching the Front Fork (Continued)

Required Tools: 13 mm Wrench and 5 mm Allen Wrench (included)



3 Be sure to properly align the slot on the headtube with the pin on the front fork as shown.




4 Reinsert the steering bolt and secure with locknut using a 13 mm wrench and a 5 mm Allen wrench.


WARNING: Failing to properly tighten the steering bolt that attaches the front fork assembly to the frame assembly can cause you to lose control and fall.

☐ Attaching the Front Wheel


Required Tools: 5 mm Allen Wrench and 10 mm Wrench (included)



1 Remove the four (4) coupling bolts from the front fork using a 5 mm Allen wrench and a 10 mm wrench.



2 Insert the wheel assembly into the front fork and align holes. When installing the wheel, make sure the letter "F" and arrow (located on the side of the wheel) are facing the direction as shown above.




3 Reinsert the coupling bolts through the front fork and tighten securely.

☐ Attaching the Seat


Required Tools: Two (2) 5 mm Allen Wrenches (included)



1 Using two (2) 5 mm Allen wrenches, remove the four (4) coupling bolts from the frame.



2 Align the four (4) holes in seat with the four (4) holes in frame. Insert the coupling bolts through the top and bottom of the frame. Note: The holes in the frame allow for one (1) of two (2) seat positions to be selected when installing the seat to the frame.



3 Tighten the coupling bolts using two (2) 5 mm Allen wrenches.

PRE-RIDE CHECKLIST Wheels Safety Gear Periodically inspect the wheels for excess wear. Always wear proper protective gear, such as an approved safety helmet. Elbow pads and kneepads are recommended. Always wear closed toe shoes (lace-up with rubber soles) and keep Frame, Fork and Handlebars shoelaces tied and out of the way of the wheels. NEVER RIDE Check for cracks or broken connections. Although broken BAREFOOTED OR IN SANDALS. frames are rare, it is possible for an aggressive rider to run into a curb or object and wreck and bend or break the frame. Get **Laws and Regulations** in the habit of inspecting your child's RipRider 360 Mini on a Always check and obey any local laws or regulations. regular basis. **Hardware/Loose Parts** Be Careful! Check and secure all fasteners before every ride. Make sure This product is not for aggressive or trick riding. Avoid steep the steering bolt and casters are tight. There should not be inclines and don't ride too fast - you can lose control and any unusual rattles or sounds from loose parts or broken fall. Skateboard parks are not designed for young riders. Never components. If the unit is damaged, do not ride. Reference ride in traffic or on the street and watch your surroundings for "Safety Warnings" on pages 1 and 2 of this manual. pedestrians, bikers, boarders and skaters. Maintain a hold on the handlebars at all times. REPAIR AND MAINTENANCE □ Cleaning Wipe with a damp cloth to remove dirt and dust. Do not use industrial cleaners or solvents, as they may damage the

□ Cleaning Wipe with a damp cloth to remove dirt and dust. Do not use industrial cleaners or solvents, as they may damage the surfaces. Do not use alcohol, alcohol-based or ammonia-based cleaners, as they may damage or dissolve the plastic components or soften the decals or decal adhesive. □ Wheels and Bearings Under normal circumstances and conditions, Razor wheels and wheel bearings are maintenance free. Nonetheless, it is the responsibility of the owner or guardian to periodically inspect the wheels for wear and tear, the axle for proper tightness, bearings for side-to-side play, and for loose parts. When a wheel develops play, this is an indication of excess wear and replacement is necessary. Replace immediately with only genuine Razor wheels. Worn wheels/ bearings are considered normal wear-and-tear and are not covered by the Razor Warranty. Wheels other than genuine Razor wheels may not be compatible with your Razor product. The use of anything other than genuine Razor replacement parts may affect your safety and will void your warranty. □ Replacement Parts The most frequently requested replacement parts are available for purchase at some Razor retail partners. For the complete selection of replacement parts visit www.razor.com.

For a list of authorized Razor repair centers:


- Check online at www.razor.com.
- Additional Customer Service contact information is listed on the back of this manual.

RIPRIDER 360° MINI CASTER TRIKE PARTS

Keep your RipRider 360° Mini Caster Trike rolling for years with genuine Razor parts. Visit our website to purchase replacement parts. (Specifications subject to change without notice.)

- 1. Handlebar Grips (Right/Left)
- 2. Front Fork
 - 2-1 Front Fork Coupling Bolts (x4)
- 3. Front Cover
- 4. Steering Bolt
 - 4-1 Lock Nut
- 5. Front Wheel w/ Pedals and Cranks Complete

- 6. Rear Wheel Complete (x2)
 - 6-1 Rear Wheel Covers (Upper/Lower)
 - 6-2 Spring Washers
 - 6-3 Casters
 - 6-4 Axle Bolts
 - 6-5 Wheels
- 7. Seat
 - 7-1 Seat Coupling Bolts (x4)
- 8. Frame Coupling Bolts (Large and Small)



WARRANTY

Razor Limited Warranty

The manufacturer warranties this product to be free of manufacturing defects for a period of 6 months from date of purchase. This Limited Warranty does not cover normal wear and tear, or any damage, failure or loss caused by improper assembly, maintenance, or storage.

This Limited Warranty will be void if the product is ever:

- used in a manner other than for recreation or transportation;
- modified in any way;
- · rented.

The manufacturer is not liable for incidental or consequential loss or damage due directly or indirectly to the use of this product.

Razor does not offer an extended warranty. If you have purchased an extended warranty, it must be honored by the store at which it was purchased.

For your records, save your original sales receipt with this manual and write the serial number below.

CUSTOMER SERVICE CONTACT INFORMATION

Need Help? Visit our website for replacement parts, product support, a list of authorized service centers in the US and customer service contact information at **www.razor.com**. Please have the product I.D. code (located on the white label of your product) available for better assistance. Additional Customer Service contact information is listed below:

AMERICAS

Razor USA LLC P.O. Box 3610 Cerritos, CA 90703 USA

+1 866 467 2967 Monday - Friday

8:00 AM - 5:00 PM Pacific Time customersupport@razorusa.com

EUROPE, MIDDLE EAST, AFRICA

Razor USA LLC (Europe) Handelsweg 2 2742 RD Waddinxveen Netherlands

+44 (0) 120 267 2702 info@razoreu.com

ASIA

Razor USA LLC (Asia) P.O. Box 3610 Cerritos, CA 90703 USA

+81 50 7579 6622 info@razor-asia.com

UNITED KINGDOM AND IRELAND

Razor USA LLC (UK) Unit 20 Hartnoll Business Centre Post Hill, Tiverton Devon EX16 4NG UK

+44 (0) 120 267 2702 info@razoreu.com

AUSTRALIA AND NEW ZEALAND

Razor USA LLC P.O. Box 4280 Auburn South VIC 3122 Australia

+1 800 954 354 (AU) +0 800 003 221 (NZ) info@razoranz.com

IMPORTED IN JAPAN BY B-PLUS ASIA CORP.

Razor USA LLC

()THE RIPSTIK COMPANY

Kurokawa 3-1, Asaoku, Kawasaki, Kanagawa 215-0035 JAPAN

+81 (0) 44 328 9057 Tel +81 (0) 44 328 9067 Fax info@razor-asia.com

Printed in China for Razor USA LLC.

Copyright © 2003-2022 Razor USA, LLC. All rights reserved. RipRider®, Razor® and the Razor logo design are among the registered trademarks of Razor USA LLC in the United States and/or select foreign countries. RipRider 360 Mini logo design is a trademark of Razor USA LLC.