

RSF350 CHAIN GUARD REPLACEMENT INSTRUCTIONS

PART #W15128001013


Required Tools: (Not included)

A. Phillips screwdriver


WARNING

CAUTION: To avoid potential shock or other injury, turn power switch <u>OFF</u> and disconnect charger before conducting any assembly or maintenance procedures. Failure to follow these steps in the correct order may cause irreparable damage.

Step 1



Step 2



ATTENTION: Charge battery 12 hours before using.