

### **Required Tools: (Not included)**


- A. Phillips screwdriver
- B. Two (2) 19 mm wrenches

# 🚹 WARNING

**CAUTION:** To avoid potential shock or other injury, turn power switch <u>OFF</u> and disconnect charger before conducting any assembly or maintenance procedures. Failure to follow these steps in the correct order may cause irreparable damage.

### Step 1

Using a Phillips screwdriver, remove six (6) screws from the deck. Remove the deck from the unit and set aside.



### Step 2

Locate and disconnect the motor connectors from the controller.



# Step 3

Using a Phillps screwdriver remove two (2) screws on each side from the axle lock nut cover.



# Step 5

Reverse the steps.

• Reposition the deck and attach with the screws that were removed in Step 1.

ATTENTION: Charge battery 8 hours before using.

#### Need Help? Visit our website at www.razor.com or call toll-free at 866-467-2967 Monday - Friday 8:00am - 5:00pm Pacific Time.

Using two (2) 19 mm wrenches, loosen the lock nuts from the axle. Slide the wheel down and pull the wires from the battery compartment.

