

W25143499079

Tools Required: (Not included)
A. Phillips screwdriver
B. Two (2) 10 mm wrenches

AWARNING

ACAUTION: To avoid potential shock or other injury, turn power switch <u>OFF</u> and disconnect charger before removing or installing the chain tensioner. Failure to follow these steps in the correct order may cause irreparable damage.

Step 1

Using a Phillips screwdriver, loosen the eight (8) screws on the motor cover, four (4) on each side, and remove cover.





Figure 1

Step 2

Loosen the three (3) Phillips screws on the chain guard and remove.




Figure 2

Step 3

Using two (2) 10 mm wrenches, loosen the locknut that secures the tensioner on to the fork and remove.




Figure 3

Note

Make sure the roller is on the outer side of the chain putting pressure against the chain.



Figure 4

Step 4

Reverse steps 1 through 3 to install replacement tensioner.

ATTENTION: Charge battery 12 hours before initial use.