

Required Tools: (Not included)

- A. 6 mm Allen wrench
- B. Phillips screwdriver

⚠ WARNING

⚠ CAUTION: To avoid potential shock or other injury, turn power switch OFF and disconnect charger before conducting any assembly or maintenance procedures. Failure to follow these steps in the correct order may cause irreparable damage.

Step 1

Using a size 6 mm Allen wrench, remove four (4) bolts from under the foot platform (two (2) on each side). Slide the platform bracket down.

**Step 2**

If replacing only the plastic platform, use a Phillips screwdriver to remove four (4) screws on top of the platform (two (2) on each side). Lift the plastic off from the bracket.



Step 3

Reverse the steps.

ATTENTION: Charge battery 12 hours before using.