

## Crazy Cart Shift 2.0 Battery Replacement Procedures



(1) Using a 4mm Allen wrench loosen up the bolt from the plastic cover next to the power switch and lift the battery cover up



(2) Using a Phillips screw driver remove two screws that hold the controller to the unit.



(3) Locate and disconnect all connectors from controller starting from the battery.



(4) Using a Phillips screw driver remove four screws from the bracket that holds the power switch.



(5) Using a small flat screw driver remove the blue and red connectors from the power switch.



(6) when re-installing the controller always connect the blue wire from controller to the prong closest to the charger port and the red wire to the middle prong.

### Reverse the procedures

- \* Place the New controller in place
- \* Re-connect all the connectors from Control Module and secure with screws
- \* Place the power switch bracket back in place and secure with screws
- \* Re-attach Battery cover with screw

**Attention: Charge battery 12 hours before using**