

### MX125 BRAKE LEVER REPLACEMENT PROCEDURES PART# W15118260011

## **Required Tools: (Not included)**

A. Phillips screwdriver

B. 5 mm Allen wrench

**C. Flathead screwdriver** 

D. 10 mm wrench

### WARNING

**ACAUTION:** To avoid potential shock or other injury, turn power switch OFF and disconnect charger before performing any assembly or maintenance procedures. Failure to follow these steps in the correct order may cause irreparable damage.

### Step 1

Using a Phillips screwdriver remove the screws on battery cover, three (3) on each side.





### Step 2


Step 4

Remove both battery covers and set aside.



# Step 3

Locate and disconnect the brake lever from the controller.



Using a 5 mm Allen wrench loosen the bolt from the brake lever and move it away from grip.



Need Help? Visit our website at www.razor.com or call toll-free at 866-467-2967 Monday - Friday 8:00 AM - 5:00 PM PST.




## Step 5

Insert a flathead screwdriver between the handlebar and the grip and add a few drops of lubricant or soapy water to slide the grip from the handlebar.



## Step 6

Cut the zip tie that holds the brake lever wire onto the frame and remove the brake lever from the unit. Using a 10 mm wrench loosen the lock nut from the brake anchor cable and remove the cable.



## Step 7

#### **Reverse the procedures**

- Replace cable.
- Connect the brake lever with the controller.
- Put battery covers back.

Attention: Charge battery 12 hours before using.