

Required Tools: (Not included)

- A. Phillips Screwdriver
- B. Two (2) 19 mm Wrenches

⚠ WARNING

⚠ CAUTION: To avoid potential shock or other injury, turn power switch OFF and disconnect charger before conducting any assembly or maintenance procedures. Failure to follow these steps in the correct order may cause irreparable damage.

Step 1

Using a Phillips screwdriver, remove the six (6) screws from the deck. Remove deck and set aside.


**Step 2**

Locate and disconnect the rear fender light from the controller.




Step 3

Using a Phillips screwdriver, remove the two (2) screws on each side from the axle lock nut cover.



Step 4

Using two (2) 19 mm wrenches, loosen the lock nuts from the axle and slide the wheel down.



Step 5

Using a Phillips screwdriver, remove the two (2) screws on each side of the rear fender.



Step 6

Using a Phillips screwdriver, remove the two (2) screws at the back of the frame. Pull and remove the fender from the frame.



Step 7

Reverse the steps to install the new rear fender brake.

ATTENTION: Charge battery 6 hours before using.